C1 - STEP 1 - WINDOW SILL MEMBRANE

C5 - STEP 2 - JAMB MEMBRANE

C7 - STEP 3 - HEAD MEMBRANE

C9 - STEP 5 - WINDOW INSTALLATION

E1 - STEP 6 - WINDOW HEAD FLASHING

E3 - STEP 7 - WEATHER BARRIER INSTALLATION

E5 - STEP 8 - JAMB FLASHING

E7 - STEP 9 - HEAD FLASHING

E9 - STEP 10 - COMPLETED WINDOW

H1 - STEP 1 - DOOR PAN FLASHING

H3 - STEP 2 - DOOR PAN FLASHING

H6 - STEP 3 - DOOR PAN FLASHING

H8 - STEP 4 - DOOR PAN FLASHING

NOTE: ROLL ALL SELF-ADHERED MEMBRANES FLAT WITH HARD FACED ROLLER TO SUBSTRATE OR UNDERLAYMENTS AT EACH STEP OF THE INSTALLATION

PERMIT REVIEW STAMP

ISSUE HISTORY

No.	Date	Description
1	1/18/2018	ISSUE FOR PERMIT

REVISION HISTORY

No.	Date	Description

© 2017 These documents and their contents are the property of FUGLEBERG KOCH - AA26002103, and are issued only for the specific project noted on these drawings. Any reproduction, reuse or modifications of these documents without the expressed written consent of Fugleberg Koch, is prohibited by law.

FUGLEBERG KOCH
2555 Temple Trail, Winter Park, FL 32789 (407) 629-0595
www.fuglebergkoch.com AA26002103

CONSULTANT

MICHAEL E. GOVE
FLORIDA LICENSE # AR94111

STATE OF FLORIDA MICHAEL E. GOVE AR94111 REGISTERED ARCHITECT

Digitally signed by Michael Gove
Date: 2018.01.22 13:57:24 -05'00'

SUMMER BAY APTS. II LAKE COUNTY, FL	Drawn: DM, AW, EB Checked: DM Approval: PF Date: Issue Date Project #: 5389

WINDOW AND DOOR TAPING PROCEDURES

A7.03

PLOTTED: 1/22/2018 9:44:55 AM